


500 Series Parts



* Denotes 4 digit code number use pump size for first number

500 Series Parts:

Stock No.	Description	Qty	Stock No.	Description	Qty	Stock No.	Description	Qty			
1	506	Gasket, Plate	8	8	523	Seal, Shaft	16	* 16	-503	Case, Center	1
2	514	Bolt, End Plate	24	9	524	Ring, Lantern	4	* 17	-510	Flange, Adapter	2
3	515	Pin, Tape	4	10	525	Bearing, Small	3	* 18	-511	Gasket, Flange	2
4	516	Fitting, Grease	8	11	526	Bearing, Large	1	* 19	-512	Flange, Bolt	8
5	518	Plug, Drain	2	12	527	Ring, Lock 2" Bearing	3	* 20	-501A	Shaft, Idler	1
6	521	Plate, Front OB	1	13	528	Ring, Lock 3" Bearing	1	* 21	-501K	Key Gear	2
7	522	Plate, Back OB	1	14	531	Plug, Expansion	3	* 22	-501G	Gear, Buna-N	2
				15	532	Ring, Lock Seal		* 23	-502A	Shaft, Drive	1

500 Series Options:

Stock No.	Description	Stock No.	Description	Stock No.	Description
25/35 EXT	Shaft, Extension	25/35 IB RK	Repair Kit	* -5 SS	Stainless Steel Shafts
25/35 SS EXT	Shaft, SS Extension	24/34 POB RK	Repair Kit	* -501 C	Steel Gear
25/35 HP	Plate, Hard Wear	24/34 POB	Gland, Packing	* -501 UG	Urethane Gear
				* -510A	Flange, Adapter Mounting

* Denotes 4 digit code number use pump size for first number